

Sensor Module Replacement

Please take the following steps to install a new sensor module. **(VERY IMPORTANT: The device MUST BE TURNED OFF in order to avoid IMMEDIATE DAMAGE to the sensor.)**



Open the easy-replace sensor panel.



You will see the sensor module.



Remove the module by pulling it straight back.



Insert a new sensor module in the original position.



Make sure the new sensor module is firmly secured.



Close the easy-replace sensor panel. Ready for testing!